

Thank you for your purchase of The CleanCut Convertible™. CleanCut has prepared these standard care and use instructions for the The CleanCut Convertible™. Please feel free to contact the installer of this product or CleanCut with any questions you may have. Again, thank you for your purchase!

- *Do not use the tub or apply weight to The CleanCut Convertible™ for two (2) days after installation to allow for the adhesive to completely dry.*
- *For use as a full bath, apply the center insert and align the holes on the left and right side of the insert with the corresponding holes on The CleanCut Convertible™ frame. Press downward on the center insert to ensure the insert is fully compressed into position. Insert the rosette knobs on each side of the center insert and tighten the rosette knobs completely.*
- *For use as a step-in shower, unscrew and remove the 2 rosette knobs. Once unscrewed, lift and remove the center insert.*
- *When not in use, store the center insert with the seals facing up and not compressed.*
- *Do not use the unit as a grab-bar or assistive device.*
- *As with any bathtub, children should not be left unattended in the bathtub.*
- *Prior to first use, please inspect the bead of caulk around the perimeter of The CleanCut Convertible™ to ensure that a continuous caulk bead has been applied and that there are no cracks or areas where caulk is absent. Conduct a similar inspection of the perimeter adhesive every six (6) months.*
- *Prior to first use, please clean and rinse the bathtub to rid the area of any dust and/or particulates that may remain after installation.*
- *Do not fill the tub with water over the opening of The CleanCut Convertible™.*
- *It is recommended that the unit be cleaned regularly with a gentle household cleaning agent. Do not use harsh cleansers or abrasive tools to clean The CleanCut Convertible™.*
- *It is recommended to completely close the shower curtain prior to turning on water to prevent water from splashing outside the bathtub.*
- *Your kit comes with 2 sets of Convertible™ Caps. Place the larger pair of Caps into frame when insert is not in place. Place the smaller pair of Caps over screws once insert is in place and screws are tightened.*

**MSDS Sheet for Enclosed Adhesive available upon request**